




ZEBCO TROPHY FEEDER 4000 FD

1-1.MAIN BODY
 1-2.BODY COVER
 1-3.SCREW
 1-4.OSCILLATING GEAR
 1-5.SCREW
 1-6.OSCILLATING SLIDER
 1-7.SCREW
 1-8.SCREW
 1-9.BODY COVER
 1-10.BODY COVER ASSEMBLY
 1-11.BALL BEARING
 1-12.WASHER
 1-13.MAIN GEAR
 1-14.BALL BEARING
 1-15.ANTI-REVERSE LEVER
 1-16.ANTI-REVERSE CAM
 1-17.SPRING
 1-18.SPRING
 1-19.SCREW
 1-20.FIXED SLICE

1-21.BALL BEARING
 1-22.BALL BEARING COVER
 1-23.ONE WAY BEARING
 1-24.MAIN SHAFT
 1-25.BALL BEARING
 1-26.PINION GEAR
 1-27.BODY COVER
 2-1. ROTOR
 2-2. SPRING
 2-3. BAIL TRIP SHAFT
 2-4. BAIL TRIP SHAFT
 2-5. ROTOR COVER
 2-6. SCREW
 2-7. SCREW
 2-8. LINE ROLLER
 2-9. WASHER
 2-10. BAIL ARM
 2-11. SCREW
 2-12. DRAG KNOB

2-13. SPOOL ASSEMBLY
 2-14. WASHER
 2-15. CLICK GEAR
 2-16. E WASHER
 2-17. LINE GUARD
 2-18. E WASHER
 2-19. ROTOR NUT
 2-20. BAIL LINE SYSTEM
 2-21. SCREW
 2-22. BAIL ARM
 3-1.HANDLE SCREW CAP
 3-2.WASHER
 3-3.HANDLE